



Start brainaids NMEA proxy.



In qtvlm start configuration>NMEA connections



Click on networksources. Toggle Server1. And fill in the IP address you see in Brainaids NMEA proxy.